

NERC

NORTH AMERICAN ELECTRIC
RELIABILITY CORPORATION

Power Plant and Transmission System Protection Coordination

Loss-of-Field (40) and Out-of-Step Protection (78)

System Protection and Control Subcommittee

Protection Coordination Workshop

Phoenix, AZ

March 17-18, 2010

to ensure
the reliability of the
bulk power system

- Objectives
- Description of Protection Functions
- Stability Fundamentals and Examples
- Discuss and Describe System Events that Could Create Conditions that Would Cause Operation of These Functions
- Seven Step Process for both Functions 40 and 78
 - Function 40 – Loss-of-Field (a.k.a. Loss-of-Excitation)
 - Function 78 – Out-of-Step

The Need for Loss-of-Field Protection – Function 40

- *“The source of excitation for a generator may be completely or partially removed through such incidents as accidental tripping of a field breaker, field open circuit, field short circuit (flashover of the slip rings), voltage regulation system failure, or the loss of supply to the excitation system. Whatever the cause, a loss of excitation may present serious operating conditions for both the generator and the system.*
- *When a generator loses its excitation, it overspeeds and operates as an induction generator. It continues to supply some power to the system and receives its excitation from the system in the form of vars.”*

The Need for Loss-of-Field Protection – Function 40

- Loss of field can occur due to:
 - Accidental tripping of a field breaker.
 - Field open circuit or field short circuit (flashover of the slip rings).
 - Voltage regulation system failure, or the loss of supply to the excitation system.

The Need for Loss-of-Field Protection – Function 40

- Loss of excitation may present serious operating conditions for both the generator and the system.
- Generator effects:
 - Generator overspeeds and operates as an induction generator receiving its excitation from the system.
 - Stator currents can exceed 2 pu causing dangerous overheating of the stator winding and core.
 - High levels of slip-frequency currents can be induced in the rotor causing over heating of the rotor.

- Power System effects:
 - A loss of field condition causes devastating impact on the power system due to loss of reactive power support from the generator.
 - Creates a substantial reactive power drain from the system.
 - On large generators this condition can contribute to or trigger a wide area system voltage collapse


The Need for Loss-of-Synchronism Protection – Function 78

- *“The protection normally applied in the generator zone, such as differential relaying, time-delay system backup, etc., will not detect loss of synchronism. The loss-of-field relay may provide some degree of protection but cannot be relied on to detect generator loss of synchronism under all system conditions. Therefore, if during a loss of synchronism the electrical center is located in the region from the high-voltage terminals of the GSU transformer down into the generator, separate out-of-step relaying should be provided to protect the machine. This is generally required for larger machines that are connected to EHV systems.*
- *On large machines the swing travels through either the generator or the main transformer. This protection may also be required even if the electrical center is out in the system and the system relaying is slow or cannot detect a loss of synchronism. Transmission line pilot-wire relaying, current-differential relaying, or phase comparison relaying will not detect a loss of synchronism. For generators connected to lower voltage systems, overcurrent relaying may not be sensitive enough to operate on loss of synchronism.”*

The Need for Loss-of-Synchronism Protection – Function 78

- During an out-of-step or pole slip condition the voltage magnitude between the generator and the system reaches two per unit (at 180 degrees) which can result in high currents that cause mechanical forces in the generator stator windings and undesired transient shaft torques.
- It is possible for the resulting torques to be of sufficient magnitude so that they cause serious damage to the shaft and to the turbine blades.
- It can cause excessive overheating and shorting at the ends of the stator core.
- It can also cause damaging transient forces in the windings of the GSU transformer as well.


Relay One-Line Showing All Generator Protection and Identifying Function 40 and 78




Stability Fundamentals

- Power System Stability - “If the oscillatory response of a power system during the transient period following a disturbance is damped and the system settles in a finite time to a new steady operating condition we say the system is stable. If the system is not stable, it is considered unstable.”
- Stability is a property of an electrical power system which has two or more synchronous machines. A system is stable for a specific set of conditions if all synchronous machines remain in step with each other. A system can be stable for one set of conditions and unstable for another.
- Transient Stability
- Swing Equation – Accelerating Torque Equals Mechanical Torque Minus Electrical Torque
- $T_a = T_m - T_e$ Newton Meters
- Equal Area Criterion


Equal Area Method to Determine Stability



- This group of protective functions (Function 40 and 78) needs to be validated against transient stability studies to insure that tripping does not occur for stable impedance swings.



Sample apparent impedance swings are presented in this figure for a dual lens characteristic out-of-step relay. In this figure the time interval between markers is 100 ms (6 cycles) such that the faster swings have greater distance between markers. The three traces represent marginally stable and unstable swings for fault clearing at and just beyond the critical clearing time, and a trace for the worst credible contingency representing the fastest unstable swing



System Events that Could Cause Undesired Operation of These Protection Functions

- Fault Conditions
- Loss of Critical Lines
- Loss of Critical Units
- Events such as August 14, 2003 Blackout
- System Islanding Conditions

Seven Step Process for both Functions 40 and 78

- This is the process used throughout the coordination Technical Reference Document to address each protective function as appropriate.
- The following slides will take a step-by-step approach through both the Function 40 and 78.
- The next two slides provide the general data and information requirements from the Generator, Transmission, and Distribution Owners.

General Data Exchange Requirements – Generator Owner Data and Information


- The following general information must be exchanged in addition to relay settings to facilitate coordination, where applicable:
 - Relay scheme descriptions
 - Generator off nominal frequency operating limits
 - CT and VT/CCVT configurations
 - Main transformer connection configuration
 - Main transformer tap position(s) and impedance (positive and zero sequence) and neutral grounding impedances
 - High voltage transmission line impedances (positive and zero sequence) and mutual coupled impedances (zero sequence)
 - Generator impedances (saturated and unsaturated reactances that include direct and quadrature axis, negative and zero sequence impedances and their associated time constants)
 - Documentation showing the function of all protective elements listed above

- The following general information must be exchanged in addition to relay settings to facilitate coordination, where applicable:
 - Relay scheme descriptions
 - Regional Reliability Organization's off-nominal frequency plan
 - CT and VT/CCVT configurations
 - Any transformer connection configuration with transformer tap position(s) and impedance (positive and zero sequence) and neutral grounding impedances
 - High voltage transmission line impedances (positive and zero sequence) and mutual coupled impedances (zero sequence)
 - Documentation showing the function of all protective elements
 - Results of fault study or short circuit model
 - Results of stability study
 - Communication-aided schemes

Document Format – Seven Sub-Sections for Each Protection Function

- Purpose
- Coordination of Generator and Transmission System
 - Faults
 - Loadability
 - Other Conditions, where applicable
- Considerations and Issues
- Setting Validation for the coordination
 - Test procedure for validation
 - Setting Considerations
- Examples
 - Proper Coordination
 - Improper Coordination
- Summary of Detailed Data Required for Coordination of the Protection Function
- Table of Data and Information that must be Exchanged

- Purpose
 - Detect and prevent unsafe and damaging operation of the generator during loss-of-excitation events.



Loss of Field protection characteristic on the R-X diagram

Figure 3.5.1 — (1) Locus of Swing Impedance during Light & Heavy Loads for LOF, and (2) Relationship between Minimum Excitation Limiter (MEL) or Under Excitation Limiter (UEL), and a Typical Condensing Operation Area

■ Faults

- Step 1 — The Transmission Owner provides the Planning Coordinator with the worst case clearing time for each of the power system elements connected to the generator bus.
- Step 2 — The Planning Coordinator determines the stability impedance trajectory for the above conditions.
- Step 3 — The Planning Coordinator provides these plots to the Generator Owner.
 - The Generator Owner utilizes these plots to demonstrate that these impedance trajectories coordinate with the time delay setting of the loss-of-field (LOF) relay to prevent misoperations by having adequate time delay.
- A system stability study may be required to evaluate the generator and system response to power system faults.
 - The response of the LOF relays under these conditions must be studied to see if they respond to power swing conditions as a result of system faults.
 - The Transmission Owner, Generator Owner, and Planning Coordinator must share information on these studies and LOF relay settings to prevent inadvertent tripping of generators for external fault conditions not related to a loss-of-field condition.
 - If there is an out-of-step protection installed it should be coordinated with the LOF protection.

Coordination of Generator and Transmission System – Function 40

- Loadability
 - Step 1 — The Generator Owners confirms that the LOF relay setting coordinates with the generator reactive capability and the excitation system capability to ensure that the LOF relay does not restrict operation of the generating unit.
 - Step 2 — A light load system study is completed in which the generator is taking in vars.
 - A sufficient number of operating conditions and system contingencies are evaluated to identify the worst case operating condition for coordination with the LOF relay setting.
 - The output of this study is provided to the Generator Owner to evaluate whether the worst case operating load condition(s) lies outside the LOF characteristic.
 - Step 3 — For any case where the operating load point lies within a properly set LOF characteristic a mutually agreed upon solution must be applied, (i.e., shunt reactor, turning off capacitor banks in the area, etc).
 - Where the solution requires real-time action by an operator the solution is incorporated into a system operating procedure.
 - Coordination between Generator Owners, Transmission Owners, and Planning Coordinators is necessary to prevent loadability considerations from restricting system operations.
 - This is typically not a problem when the generator is supplying VARs because the LOF characteristics are set to operate in third and fourth quadrant.
 - However, when the generator is taking in VARs due to light load and line charging conditions, or failure of a transmission capacitor bank to open due to control failure, loss-of-field relays can misoperate if the apparent impedance enters the relay characteristic in the fourth quadrant.


- The LOF relay settings must be provided to the Planning Coordinator by the Generator Owner so that the Planning Coordinator can determine if any stable swings encroach long enough in the LOF relay trip zone to cause an inadvertent trip.
- The Planning Coordinator has the responsibility to periodically verify that power system modifications do not result in stable swings entering the trip zone(s) of the LOF relay causing an inadvertent trip.
- If permanent modifications to the power system cause the stable swing impedance trajectory to enter the LOF characteristic, then the Planning Coordinator must notify the Generator Owner that new LOF relay settings are required.
- The Planning Coordinator should provide the new stable swing impedance trajectory so that the new LOF settings will accommodate stable swings with adequate time delay. The new settings must be provided to the Planning Coordinator from the Generator Owner for periodic assessment in future studies.

- The coordination requirements with generator controls are such that the loss-of-field relay must not operate before the UEL limit (with a margin) is reached.


Example - Proper Coordination

– Function 40

- Typical Loss-of-Field Relay Setting Calculation for two zone offset mho characteristic (calculations are in transmission system primary ohms).
- Step-1 — Calculate the Base impedance = 17.56 Ω /per unit
- Step-2 — Convert $X'd$ and X_d in per unit to Ohms:
 - 3.61 Ω
 - 20.88 Ω
- Step-3 — Element settings:
 - Offset = (50%) ($X'd$) = (0.5) (3.61) = 1.8 Ω
 - $Z_1 = 1 \text{ pu} = 17.6 \Omega$
 - $Z_2 = = 20.88 \Omega$
- Step-4 — Plot various characteristics as shown in figure 3.5.1
- Step-5 — set the time delays for zone 1 and zone 2 elements.
 - Typical time delay settings are:
 - Zone 1: 0.1 sec
 - Zone 2: 0.5 sec
- System stability studies should be conducted to see if the above time delays are sufficient to prevent inadvertent tripping during stable power swings.
- Figure 3.5.3 illustrates some of these types of swing characteristics that need to be studied.
- Step-6 — Set the undervoltage supervision (if appropriate):
 - $V = 85\% \text{ of } = 0.85 \times 120V = 102 \text{ V}$



Example - Proper Coordination – Function 40



System stability studies should be conducted to ensure the time delay settings are sufficient to prevent inadvertent tripping during stable power swings.

Summary of Protection Functions Required for Coordination – Function 40

Table 2 Excerpt — Device 40 Protection Coordination Data Exchange Requirements

Generator Protection Device	Transmission System Protection Relays	System Concerns
40 – Loss of Field (LOF)	Settings used for planning and system studies	<ul style="list-style-type: none"> • Out-of-Step — survive stable swings • Preventing encroachment on reactive capability curve • Transmission Owner(s) need to exchange Reactive power (VAR) capability from Generator Owner(s) • See details from sections 4.5.1 & A.2.1 of C37.102-2006 • The setting information for the LOF relay should be provided by the Generator Owner to the Transmission Owner and Planning Coordinator in order for this information to be available to the appropriate planning entity. The impedance trajectory of most units with a lagging power factor (reactive power into the power system) for stable swings will pass into and back out of the first and second quadrants. It is imperative that the LOF relay does not operate for stable power swings. • The LOF relay settings must be provided to the appropriate planning entity by the Generator Owner so that the planning entity can determine if any stable swings encroach long enough in the LOF relay trip zone to cause an inadvertent trip. The appropriate planning entity has the responsibility to continually verify that power system modifications never send stable swings into the trip zone(s) of the LOF relay causing an inadvertent trip. If permanent modifications to the power system cause the stable swing impedance trajectory to enter the LOF characteristic, then the planning entity must notify the Transmission Owner who in turn must notify the Generator Owner that new LOF relay settings are required. The planning entity should provide the new stable swing impedance trajectory so that the new LOF settings will accommodate stable swings with adequate time delay. The new settings must be provided to the planning entity from the Generator Owner through the Transmission Owner for future continuous monitoring. • Transmission Owners must provide system information and appropriate parameters to enable the Generator Owners to conduct a system study. This enables the Generator Owner to fine tune LOF settings if required.

Protection Function Data and Information Exchange Required for Coordination – Function 40

Table 3 Excerpt — Device 40 Data To be Provided

Generator Owner	Transmission Owner	Planning Coordinator
Relay settings: loss of field characteristics, including time delays, at the generator terminals.	The Transmission Owner provides the Planning Coordinator with the worst case clearing time for each of the power system elements connected to the transmission bus at which the generator is connected.	Impedance trajectory from system stability studies for the strongest and weakest available system Feedback on problems found in coordination and stability studies

Loss of Synchronism – Function 78

- Purpose
 - Detect and prevent unsafe and damaging operation of the generator during out-of-step events.




Figure 3.13.1 — Loci of Swing by E_g/E_s

Loss of Synchronism – Function 78

- Figures 3.13.1A and 3.13.1B illustrate a simple representation of two (2) systems E_s (power system) and E_g (a generator) connected through a GSU transformer.
 - Figure 3.13.1C shows typical power swing loci which are dependent on the ratio of E_g / E_s .
 - When E_g is less than E_s , which may occur when the generator is underexcited, the power swing loci will appear electrically “closer” to the generator than the power system.
 - Due to the variability of the apparent impedance trajectory it is desirable to base out-of-step protection settings on transient stability simulations.

Coordination of Generator and Transmission System – Function 78

- **Faults**
 - There are no coordination issues for system faults for this function, although the apparent impedance swings for which out-of-step protection must be coordinated often occur as the result of system faults.

- **Loadability**
 - There are no coordination issues related to loadability for this function.

Coordination of Generator and Transmission System – Function 78


- Other Operating Conditions

- A generator may pole-slip (out-of-step or loss-of-synchronism), or fall out of synchronism with the power system for a number of reasons. The primary causes are:
 - Prolonged clearance of a low-impedance fault on the power system.
 - Generator operation at a high load angle close to its stability limit.
 - Partial or complete loss of excitation.
- To properly apply this protection function, stability studies must be performed. These studies:
 - Require extensive coordination.
 - Usually are conducted by the Transmission Planner or Planning Coordinator.
 - Should evaluate a wide variety of system contingency conditions.
- Out-of-step protection
 - Should not be applied unless stability studies indicate that it is needed.
 - Should be applied in accordance with the results of those studies.
 - Must be reviewed as system conditions change.

Coordination of Generator and Transmission System – Function 78

- Other Operating Conditions (continued)
 - Studies must be used to verify that the out-of-step protection:
 - Provides dependable tripping for unstable swings.
 - Provides secure operation for stable swings.
 - The critical conditions for setting the relay are:
 - The marginal condition representing the unstable swing that is closest to a stable condition.
 - The fastest swing typically resulting from the most severe system condition.
 - Typically the out-of-step settings are developed by:
 - Calculating initial settings for blinders, time delay, etc. using a graphical approach.
 - Refining the settings as necessary based on transient stability simulations.
 - This process requires an exchange of information between the Transmission Owner(s), the Generator Owners(s) and the Transmission Planner and/or Planning Coordinator.

1. Model the overall system and carry out transient stability runs for representative operating conditions. The modeling of the generators should include the voltage regulator, generator governor and power system stabilizer (PSS) if in service.
2. Determine values of generator transient reactance (X'_d), unit transformer reactance (X_{TG}) and system impedance under maximum generation (X_{maxSG1}).
3. Set the Mho unit to limit the reach to 1.5 times the transformer impedance in the system direction. In the generator direction the reach is typically set at twice generator transient reactance. Therefore the diameter of the MHO characteristic is $2 X'_d + 1.5 X_{TG}$.
4. Determine by means of the transient stability runs, the critical angle δ between the generator and the system by means of the transient stability simulations. This is the angle corresponding to fault clearing just greater than the critical clearing time.




Coordination Procedure (cont.)


5. Determine the blinder distance d , which is calculated with the following expression:

$$d = \left(\left(\frac{X'_d + X_{TG} + X_{\max SG1}}{2} \right) x \tan(90 - \delta/2) \right)$$

6. Determine the time for the impedance trajectory to travel from the position corresponding to the critical angle δ to that corresponding to 180° . This time is obtained from the rotor angle vs. time curve which is generated by the transient stability study for the most severe transmission fault, when the system experiences the first slip.
7. The time delay of the 78 function should be set equal to the value obtained from the transient stability study in step 6. This value is equal to half the time for the apparent impedance to travel between the two blinders and provides adequate margin to permit tripping for faster swings, while providing security against operation for fault conditions.



Determination of Timer Setting



Determination of Timer Setting

- The fault inception will be considered at $t = 0.5$ seconds
- Clearing times starting at $t = 90$ ms (approx. 5 cycles) will be used in consecutive steps of 10 ms.
- For simplicity, the fault is removed with the consequent outage of the line.
- The voltage regulator is IEEE type ST1 excitation system.
 - This voltage regulator is of static excitation type where the rectifiers provide enough DC current to feed the generator field.
 - The model represents a system with the excitation power supplied from a transformer fed from the generator terminals or from the auxiliary services and is regulated by controlled rectifiers.
- The turbine-governor is IEEE type 1 Speed Governing Model. This model represents the system of speed control (Mechanical-Hydraulic) and steam turbine.
- For this machine no power system stabilizer is available.

Determination of Timer Setting




Figure G-4

Determination of Timer Setting

- Several plots from the transient stability runs can be obtained for a myriad of applications. For setting out-of-step elements the most important information is the Rotor Angle vs. Time and $R + j X$ vs. time.
- From the respective plots it can be observed that:
 - In Case 1, with a clearing time of 90 milliseconds, the system remains in synchronism.
 - In Case 2, G1 and the system are still in synchronism with a clearing time of 180 milliseconds.
 - In Case 3, G1 loses synchronism with a clearing time of 190 ms. From the above it is evident that the critical time to clear the fault is equal to 180 ms after fault inception.
- The rotor angles for the three cases are shown in Figure G-4, from which it can be seen that the critical angle is approximately 140° . The time for the swing locus to travel from the critical angle to 180° is approximately 250 milliseconds.
- Therefore the time delay setting should be set to 250 milliseconds.

Determination of Timer Setting

- R vs. X diagrams for the three cases show the impedance trajectory seen by the relay during the disturbances. When there is an oscillation in the generator which is stable, the swing locus does not cross the impedance line.
- When generator goes out-of-step, the transient swing crosses the system impedance line each time a slip is completed and the relay should trip the generator.
- Figure G-6 shows the R vs. X diagram for cases 1, 2, and 3.
 - In the first two cases it is clear that the load point does not cross the system impedance line.
 - For case 3, the load point crosses the system impedance line indicating that the synchronism is lost and therefore out-of-step tripping must be allowed.

Determination of Timer Setting





Figure G-6

Example - Proper Coordination

- Function 78



- Conversion 100MVA/138KV into 492MVA/20KV base:

$$Z_{1,max} = 0.0005 + j0.0100 \text{ pu on } 100\text{MVA}/138\text{KV}$$

$$Z_{new} = \frac{(492)(138)^2 (19)^2}{(100)(145)^2 (20)^2} Z_{origin} = 4.0219 Z_{origin}$$

$$Z_{1,max} = 4.0219 (0.0005 + j0.0100 \text{ pu}) = 0.0020 + j0.0402 \text{ pu on } 492\text{MVA}/20\text{KV}$$

- Conversion of various reactance into 492MVA base:

$$Z_{base} = \frac{20\text{KV} / (1.732\text{VTR})}{14202/\text{CTR}} = \frac{69.28}{3.945} = 17.56 \Omega / \text{pu}$$

$$X'd = (0.20577 \text{ pu})(17.56) = 3.61 \Omega$$

$$X_d = (1.1888 \text{ pu})(17.56) = 20.88 \Omega$$

$$X_t = 2.3 \Omega$$

- Calculation of Diameter and Blinder:

$$\text{Diameter} = 1.5X_t + 2X'd = 1.5 \times 2.3 + 2 \times 3.61 = 10.67 \Omega$$

$$\text{Center of Mho unit} = (10.67/2) - 3.45 = 1.9 \Omega$$

$$\begin{aligned} \text{Blinder} &= [(X'd + X_t)/2] \tan(90 - (120/2)) = \\ &= [(3.61 + 2.3)/2] \tan(30) = \\ &= (2.955) \tan(30) = 1.7 \Omega \end{aligned}$$

■ Check List


- The direct axis transient reactance ($X_{d'}$) used in the setting calculation should be on the generator voltage base.
- The GSU transformer reactance (X_t) used in the setting calculation should be on the generator voltage base.
- The reverse reach should be greater than GSU transformer reactance (X_t).
- A proper angular separation δ [1] between the generator and the system should be used to set the blinders (as determined by a transient stability study).
- A power system stability study should be performed for the relay time delay setting.

[1] Note: Pursuant to C37.102, with regard to setting of the blinder, the angle δ is the angular separation between the generator and the system, at which the relay determines instability. If a stability study is not available, this angle is typically set at 120° .

Example - Proper Coordination

– Function 78

- Assumptions:
- 2.26-Ω/phase, 50% of 2.26-Ω/phase = 1.13-Ω/phase, 145-kV
- Reverse Reach – = 2.26 - Ω/phase
- Forward Reach – = 2 x 3.61 = 7.22-Ω/phase
- Diameter of Mho Element – D = 9.48-Ω
- Center of Mho Element – C = (D/2)- = (9.48/2) – 2.26 = 2.48 ==> (-2.48, 0)
- Blinders – $d1 \ \& \ d2 = \{(X'd + Xt)/2\} \tan \{90^\circ - (140^\circ/2)\} = \{(3.61 + 2.3)/2\} \tan \{90^\circ - (140^\circ/2)\} = 2.955 \tan 20^\circ = 1.08\text{-}\Omega$



NOTE: Settings should be validated and refined as necessary based on transient stability simulations.

Summary of Protection Functions Required for Coordination – Function 78

Table 2 Excerpt — Device 78 Protection Coordination Data Exchange Requirements

Generator Protection Device	Transmission System Protection Relays	System Concerns
78 — Out-of-Step	21 (Coordination of OOS blocking and tripping) Any OOS if applicable	<ul style="list-style-type: none">• System studies are required• Settings should be used for planning and system studies either through explicit modeling of the device, or through monitoring impedance swings at the device location in the stability program and applying engineering judgment

Protection Function Data and Information Exchange Required for Coordination – Function 78

Table 3 Excerpt — Device 78 Data To be Provided

Generator Owner	Transmission Owner	Planning Coordinator
Relay Settings, Time Delays and Characteristics for out-of-step trip and blocking	Provide relay settings, time delays and characteristics for the out-of-step block and trip if used	Determine if there is a need for transmission line out-of-step blocking/tripping related to the generator Feedback on coordination problems found in stability studies.

What is Important to Coordination

- Settings that Protect the Generator
- Critical Clearing Time
- Worst Case Survivable Condition
- Sufficient Studies

Settings that Protect the Generator

- The generator protection set-points are described in the IEEE Guide for AC Generator Protection (C37.102) for both Function 40 and 78 based on machine and system reactance.
- The time to trip are adjusted based on the specific generator and application.
- Examples of these were given in the presentation, but again, specific settings need to be determined by the entities.

- Clearing time directly impacts the ability to return to a stable system following a system disturbance.
- If fault clearing exceeds the unit critical clearing time then the machine will lose synchronism with the system and is required to trip.

Worst Case Survivable Condition

- The protection must be set to avoid unnecessary tripping for worst case survivable conditions:
 - Operation of transmission equipment within continuous and emergency thermal and voltage limits
 - Recovery from a stressed system voltage condition for an extreme system event – i.e. 0.85 pu voltage at the system high side of the generator step-up transformer
 - Stable power swings
 - Transient frequency and voltage conditions for which UFLS and UVLS programs are designed to permit system recovery
- When coordination cannot be achieved without compromising protection of the generator, the generator protection setting must be accounted for in system studies.

- The Planning Coordinator must study a number of operating conditions sufficient to bound the worst case.
- Assess sensitivity of generator and system response to:
 - System load level
 - Generator loading (both active and reactive power)
 - Commitment and dispatch of other generators
 - System operating states (N-0, N-1, . . .)
- The most limiting operating condition may vary among protective functions or even for different settings for a single protective function.



Question & Answer

Contact:

Phil Tatro, System Analysis
and Reliability Initiatives

phil.tatro@nerc.net

508.612.1158