

## Reporting Event Details

Data Reporting Instructions - Section III

Module 08 - GADS Data Reporting Workshops June, 2019

#### RELIABILITY | ACCOUNTABILITY













- The 07 event data file has four (4) sections
  - A Event identification C Primary Cause of Event
  - B Event magnitude D Additional Work During Event (up to 48)

Record Code 07 Event Data File Format							
One (1) Event on One (1) Unit = 3 records + 2 Per Additional Work During Event = 99 Records Max							
07 Section A - Event Identification, col 1 - 19	Section B - Event Magnitude, col 20 - 82	01					
07 Section A - Event Identification, col 1 - 19	Section C - Primary Cause of Event, col 20 - 82	02					
07 Section A - Event Identification, col 1 - 19	Section C - Primary Cause of Event, col 20 - 82	03					
07 Section A - Event Identification, col 1 - 19	Section D - Additional Work During Event, col 20 - 82	04					
07 Section A - Event Identification, col 1 - 19	Section D - Additional Work During Event, col 20 - 82	05					

- Section A 7 data fields
- Section B 6 data fields
- Section C 9 data fields (Even), 3 data fields (Odd)
- Section D 9 data fields (Even), 3 data fields (Odd)
- Even/Odd = Record Numbers for Sections C/D which have two records each, one even, one odd, up to 99 max

#### 07 Event Data File



- Only the 07 event data file format is accepted by webE-GADS
  - To see if your program is using the correct format
    - Open the event file with Notepad
    - o If the first two digits of the file are 07 you have the right file format
    - If the first two digits of the file are 97 then update your software

```
073873812017
               370MB01010000
                                                  12312400
                                                                                      01
                                                                      Mothballed
                                                                                      02
                                                                                      01
                                                  12312400
                                                                      Mothballed
                                                                                      02
               200MB01010000
                                                  12312400
                                                                                      01
                                                                                      02
                                                                      Mothballed
073873832017
              200MB9991
```

- All event data files must be text files and have the file extension "txt" or it will not upload to webE-GADS
- Data is due 45 days after the end of each quarter
- Monthly or year-to-date data is accepted by webE-GADS
  - Monthly: Q1 = Jan thru Mar, Q2 = Apr thru Jun
  - Year-To-Date: Q1 = Jan thru Mar, Q2 = Jan thru Jun (recommended)



#### Note On Data vs. Data File Rules

- The DRI contains rules about the data you are required to collect
  - These rules must be followed when collecting the GADS data
  - Example:
    - Outages can never overlap
      - An outage that starts during another outage will cause an error
- The DRI also contains rules about the format the data must be in to be submitted to GADS
  - These rules must be followed when creating the files you submit to GADS
  - Example:
    - The format in Section B of the 05 performance data file assumes two decimals in each of the six unit generation performance values reported in it

Data: 1234567.8 ends in .8, one decimal

- File: 123456780 no decimal point, zero added for 2 decimals

The two sets of rules are mutually exclusive



- Problem: Unit A completes a planned outage. The critical path involved replacing the generator but there were 40 other items worked on during the outage and your boss wants you to include them for the record
- Question: How many 07 event data file records will be required for the planned outage event plus the additional 40 items?
  - A. 41
  - B. 43
  - C. 83
  - D. 81
- Answer: C. 83
- Explanation: # records = 3 + 2 per additional work during event = 3 + 2\*40 = 83; the maximum is 99 records





#### 07 Event Data File: Section A - Event Identification, Record 01

Data Field	Columns	07			
Record Code	01-02				
Utility (Company) Code	03-05				
Unit Code	06-08		 r		
Year	09-12				
Event Number	13-16		 	 ****	
Report Revision Code	17		 		
Event Type	18-19		 	 	 ne



- Section A is used to identify the event
  - Which utility-unit did the event occur on?
  - What type of event was it?
- There are seven (7) data fields per record as shown above

#### **Event Identification**



#### Required fields:

- Record Code
  - The 07 record code uniquely identifies the data as an event data file record
- Utility (Company) Code
  - Three character alpha-numeric code identifying the reporting organization
  - Assigned by OATI for NERC
- Unit Code
  - Three-digit code identifying the unit reported
  - Code distinguishes one unit from another in a utility
  - Code range is restricted by the unit type
- The combination of utility and unit codes uniquely identifies a unit in the GADS database
  - Example: 840331 Utility=840, Unit=331

#### **Event Identification**



- Required fields:
  - Year
    - The year the event occurred
  - Event Number
    - Unique for each event on a unit in a given year
    - Need not be sequential
    - Recommend they be chronological
- Events start when they start and end when they end events that continue through multiple months/years should be tracked as one long event and not ended/re-started each month/year
- The combination of Utility Code, Unit Code, Year, and Event Number uniquely identifies an event in the GADS database
  - Example: 8403311995137 Utility=840, Unit=331, Year=1995, Event=137

#### **Event Identification**



- Report Revision Code (voluntary)
  - Shows changes to the event record
    - Original Reports (0)
    - Additions or corrections (1, 2,...9)
    - Even if just one record is revised resubmit all of the records for the revised time period
- Event Type Code (required)
  - Identifies the state experienced by the unit
    - Inactive State divided into three (3) event types
    - Active State divided into seventeen (17) event types



- Problem: Section A of the 07 event data file contains the event identification information
- Question: Which of the following is not required in Section A?
  - A. Record Code, col 1 2
  - B. Revision Code, col 17
  - C. Event Type, col 18 19
  - D. Utility Code, col 3 5
  - E. Event Number, col 13 16
- Answer: B. Revision Code
- Explanation: Revision Code shows changes to the event record and is voluntary; all other fields are required



or Event bata i noi occioi		9,,,,,	and the	The second second		
Data Field	Columns					01
Start of Event	20-27					
Blank Columns	28-47					
End of Event	48-55					
Gross Available Capacity	56-61					
Net Available Capacity	62-67					
Blank Columns	68					
Dominant Derating Code	69					
Blank Columns	70-80					
Record Number	81-82				 	



- Section B is used to describe the impact of the event
  - How long did the event last?
  - How large an impact did the event have on unit capacity?
- There are six (6) data fields per record as shown above

#### **Start Of Event**



- Start of Event (required)
  - Start month, day, hour, minute
- Outages start when the unit
  - Is desynchronized
  - Enters a new outage state
- Reserve Shutdowns start when the unit
  - Is desynchronized
  - Enters the reserve shutdown state from another state
- Derates start when
  - A major component or piece of equipment is taken out of service
  - The unit experiences a problem preventing it from making full load
    - Small boiler tube leak
- Use a 24-hour clock when reporting the start of event to GADS



- End of Event (required by year's end)
  - End month, day, hour, minute
- Outages end when the unit
  - Is synchronized
  - Enters another appropriate unit state
- Reserve Shutdowns end when the unit
  - Is synchronized
  - Enters another appropriate unit state
- Derates end when
  - A major component or piece of equipment is available for service
  - A problem that had prevented the unit from running at full load is fixed
    - Fuel oil gun finally goes in service
- Use a 24-hour clock when reporting the end of event to GADS

# NERC NORTH AMERICAN ELECTRIC RELIABILITY CORPORATION

## **Using the 24-hour Clock**


- If the event starts at midnight, use:
  - 0000 as the start hour and start time
- If the event ends at midnight, use:
  - 2400 as the end hour and end time
- This is a data file formatting rule
  - Your in-house GADS system may not use a 24 hour clock. In that case your system must reformat the end time of the event when recorded in the 07 event data file using a 24 hour clock format as shown above
  - This will not end your event at the end of a year; GADS will connect both pieces of an event spanning the end of a year back together
  - The reason each event must end at the end of the year in the data file you submit to GADS is because you only enter the month, day, hour, and minute for the start/end times on the events in Section B. The year is in Section A, as a single value, which is used for both the start and end of the event, so the event can't cross years in data file itself.



- Problem: Your software package does not use a 24-hour clock. If an event starts at midnight on 06/10/19 you can enter 06/10/19 00:00 AM which is OK. But if the event ends at midnight you can enter 06/10/19 11:59 PM at best or 06/11/19 00:00 AM, which is the same thing as 2400, but the day has changed.
- Question: What kind of rule is it that requires you to use a 24hour clock?
  - A. Data collection rule
  - B. Data formatting rule for the file you submit to GADS
- Answer: A. Data collection rule
- Explanation: Your software package will convert 06/11/19 00:00 AM to 06/10/19 24:00 for inclusion in the file you submit to GADS



### **Unit Capacity Levels**



Available capacities are to be expressed on either a gross or net basis

## **Available Capacity**



- Gross Available Capacity (voluntary)
  - This is the level of gross generation the unit can achieve while being derated
- Net Available Capacity (required)
  - This is the level of net generation the unit can achieve while being derated
- Dominant Derate Code (voluntary)
  - Enter a D to indicate that a derate is dominant
- Record Number (required)
  - 01 uniquely identifies it as the first record in the event data file



## **Capacity Estimation Factors**

- If only GAC or NAC is reported during a derate the missing value will be estimated using a capacity estimation factor (CEF) for the unit type
  - Example: GAC = NAC \* (1 + CEF)

Unit Type	Unit Code Range	CEF
Combined Cycle GT units	300-399, 700-799	2.00
Combined Cycle ST units	100-199, 600-649	5.00
CoGeneration GT units	300-399, 700-799	2.00
CoGeneration ST units	100-199, 600-649	5.00
CoGeneration Block	800-899	4.00
Combined Cycle Block	800-899	4.00
Fluidized Bed	650-699	5.00
Fossil-Steam	100-199, 600-649	5.00
Gas Turbine/Jet Engine (Simple Cycle Operation)	300-399, 700-799	2.00
Geothermal	800-899	4.00
Internal Combustion/Reciprocating Engines	400-499	0.00
Miscellaneous	800-899	4.00
Multi-boiler/Multi-turbine	800-899	4.00
Nuclear	200-299	5.00
Pumped Storage/Hydro	500-599, 900-999	2.00



- Problem: Section B of the 07 event data file contains the event magnitude information
- Question: For which event types should you report GAC/NAC?
  - A. All events
  - B. Only forced outage events
  - C. Derate events
  - D. Reserve Shutdowns
- Answer: C. Derate events
- Explanation: GAC/NAC are reported for derate events only; they are needed to determine the reduction on unit output



## **Allowable Event Type Changes**

то											
FROM	U1	U2	U3	SF	MO	PO	ME	PE	RS	DM	DP
U1 – Immediate	Yes	No	No	Yes	Yes	Yes	No	No	Yes		
U2 – Delayed	Yes	No	No	Yes	Yes	Yes	No	No	Yes		
U3 – Postponed	Yes	No	No	Yes	Yes	Yes	No	No	Yes		
SF - Startup Failure	Yes	No	No	Yes	Yes	Yes	No	No	Yes		
MO – Maintenance	Yes	No	No	Yes	Yes	Yes	Yes	No	Yes		
PO – Planned	Yes	No	No	Yes	No	Yes	No	Yes	Yes		
ME – Maintenance Extension	Yes	No	No	Yes	Yes	No	No	No	Yes		
PE – Planned Extension	Yes	No	No	Yes	No	Yes	No	No	Yes		
RS – Reserve Shutdown	Yes	No	No	Yes	Yes	Yes	No	No	Yes		
D1 – Immediate										No	No
D2 – Delayed										No	No
D3 – Postponed										No	No
D4 – Maintenance	IEEE Standard 762 does not recognize									Yes	No
PD – Planned		transition to/of deratings from/to								No	Yes
DM – Maintenance Derating	]	other event types except as shown.								No	No
Extension	]										140
DP – Planned Derating										No	No
Extension											

#### **Event Transitions**



- Yes indicates an allowed transition from one event type to another
- No indicates an illegal transition from one event type to another
- There are seven (7) general types of transitions
  - All outages can transition to U1 but not U2 or U3
  - All outages can transition to SF
  - All outages except PO and PE can transition to MO
  - All outages except ME can transition to PO
  - All outage extensions must follow outages of the same type
  - All outages can transition to RS
  - Derates may transition to their extensions only



- Problem: You are trying to enter your GADS data for the month and you keep getting a strange error. You have checked and verified that all of the data was typed in correctly. You dig deeper and find that the error is due to an invalid event transition which you fix by correcting an event type.
- Question: Which event type transition is invalid?
  - A. PO to PE
  - B. D4 to DM
  - C. RS to U2
  - D. U3 to U1
- Answer: C. RS to U2
- Explanation: RS is an offline state while a U2 can only occur from an online state



## **Primary Cause Of Event**

- Details the primary cause of event
  - What caused the event?
  - It may not always be the root cause
- There are two records in Section C as shown on the next slide
  - There are nine (9) data fields in the even numbered record (02)
  - There are three (3) data fields in the odd numbered record (03)
    - If the verbal description is less than 32 characters the second Section C record can be omitted



## **Primary Cause Of Event**

07 Event Data File: Section C - Primary Cause of Event, Record 02

Data Field	Columns					02
						0.2
Cause Code	20-23					
Amplification Code	24-25					
Time Work Started	26-33					
Time Work Ended	34-41					
Blank Columns	42-43					
Event Contribution Code	44					
Problem Alert	45					
Man-hours Worked	46-49					
Verbal Description	50-80	 	 	 		
Record Number	81-82	 	 	 	 	



07 Event Data File: Section C - Primary Cause of Event, Record 03

		-		
Data Field	Columns			03
Cause Code	20-23			
Blank Columns	24-25			
Verbal Description	26-80			
Record Number	81-82			



### Cause Code (required)

- 4-digit number
- 1,700+ cause codes currently in GADS
- Points to the equipment with a problem and/or cause of the event
- Sets of cause codes are available for each type of unit
  - See DRI Appendices B01-15
  - o Each appendices is indexed alphanumerically by system, component, and sub-component; some tables do not (yet) have sub-component data
  - The main index has a link to each table for easy access
  - Each table is indexed numerically by cause code
  - All System, Component, and Sub-Component names are standardized
  - o Except for a few exceptions all cause code descriptions are standardized as well
  - Any applicable notes are located at the bottom of each table for easy reference
  - The entire document is searchable



### Sample cause code table

Unit Type Fossil Steam

AppendicesB08

Table16

System Balance of Plant

Component Condensate System

Sub-Component: Pumps, Piping, and Valves

Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3310 Condensate/hotwell pumps Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3311 Condensate/hotwell pump motor Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3312 Condensate booster pump Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3313 Condensate booster pump motor Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3314 Condensate booster pump motor - variable speed Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump motor - variable speed Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314)	UNIT TYPE	SYSTEM	COMPONENT	SUB-COMPONENT	CAUSE CODE	DESCRIPTION
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3311 Condensate/hotwell pump motor  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3312 Condensate booster pump  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3313 Condensate booster pump motor  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3314 Condensate booster pump motor - variable speed  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314)  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping  Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3300	Condensate water pre-treatment
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3312 Condensate booster pump Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3313 Condensate booster pump motor Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3314 Condensate booster pump motor - variable speed Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314) Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3310	Condensate/hotwell pumps
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3313 Condensate booster pump motor Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3314 Condensate booster pump motor - variable speed Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314) Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3311	Condensate/hotwell pump motor
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3314 Condensate booster pump motor - variable speed Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314) Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3312	Condensate booster pump
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3315 Condensate booster pump drive (other than 3313 and 3314) Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3313	Condensate booster pump motor
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3320 Condensate piping Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3314	Condensate booster pump motor - variable speed
Fossil-Steam Balance of Plant Condensate System Pumps, Piping, and Valves 3330 Condensate valves	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3315	Condensate booster pump drive (other than 3313 and 3314)
	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3320	Condensate piping
	Fossil-Steam	Balance of Plant	Condensate System	Pumps, Piping, and Valves	3330	Condensate valves





Unit Type	Unit Code Range	Appendix
Combined Cycle GT units	300-399, 700-799	B01
Combined Cycle ST units	100-199, 600-649	B02
CoGeneration GT units	300-399, 700-799	B03
CoGeneration ST units	100-199, 600-649	B04
CoGeneration Block	800-899	B05
Combined Cycle Block	800-899	B06
Fluidized Bed	650-699	B07
Fossil-Steam	100-199, 600-649	B08
Gas Turbine/Jet Engine (Simple Cycle Operation)	300-399, 700-799	B09
Geothermal	800-899	B10
Internal Combustion/Reciprocating Engines	400-499	B11
Miscellaneous	800-899	B12
Multi-boiler/Multi-turbine	800-899	B13
Nuclear	200-299	B14
Pumped Storage/Hydro	500-599, 900-999	B15



- Problem: A feral cat gets into the auxiliary bus room on Unit 2.
   While chasing a mouse it steps across two conductors creating a conductive path. While the electricians are tasked with cleaning up what's left of the cat and repairing the damage done to the auxiliary bus you are tasked with reporting the event to GADS.
- Question: Which cause code should you use?

A. 3662 4000-7000 volt conductors and buses

B. 3669 Other 4000-7000 volt problems

C. 9040 Other catastrophe

D. 9320 Other miscellaneous external problems

E. 9720 Other safety problems

Answer: E. 9720

 Explanation: The cause of the event was not due to voltage or external problems, nor to a catastrophe; it was due to poor housekeeping which is considered a safety problem

## **Amplification Codes**



- Two alpha character code used to describe the failure mode or reason for failure (Appendix J)
- Used by Canadian Electricity Association (CEA) and International Atomic Energy Agency (IAEA) as modifiers to codes for many years
- Increases the resources of cause codes without adding new codes
- Many Amplification Codes are the same as the Failure Mechanism codes (Appendix H)
- Only required for U1 events that occur from an online state;
   strongly recommended for all other events



## **Amplification/Failure Code Examples**

Amplific	cation Code	Failure C	Code
03	Arced/flashover – electrical	F030	Arced/flashover – electrical
06	Broken	F060	Broken
12	Clogged	F120	Clogged
28	Cracked	F280	Cracked
42	Error, operator	F420	Error, operator
53	Inspection	F530	Inspection
55	Loose	F550	Loose
72	Sticking	F720	Sticking
81	Torn	F810	Torn
42	Error, operator	FP00	Personnel error
RO	Fire	FR00	Fire
V0	Vibration (other)	FV00	Vibration



- Problem: A feral cat gets into the auxiliary bus room on Unit 2.
   While chasing a mouse it steps across two conductors creating a conductive path. While the electricians are tasked with cleaning up what's left of the cat and repairing the damage done to the auxiliary bus you are tasked with reporting the event to GADS.
- Question: Which amplification code should you use?
  - A. 08 Burned/fire damage not initiated by component
  - B. 10 Carbon, covered
  - C. 30 Damaged, foreign object
  - D. 45 Explosion damage not initiated by the component
  - E. 49 Grounded electrical component
- Answer: E. 49 Grounded electrical component
- Explanation: While the cat did catch fire, which covered the bus with carbon, and parts of the cat did do damage where they landed after the explosion, the problem was due to grounding

# NERC NORTH AMERICAN ELECTRIC RELIABILITY CORPORATION

#### **Event Contribution Code**

- Time: Work Started/Time: Work Ended (voluntary)
  - Use 24 hour clock
  - GADS uses the event start/end dates/times if not provided
- Event Contribution Code (voluntary)
  - Primary cause of event 1
    - Forced outages have only one primary cause
    - PO and MO events can have multiple primary causes for PO and MO events
  - Contributed to primary cause of event 2
    - Contributed but not primary
  - Work done during the event 3
    - Worked on during event but did not initiate an event
  - After startup, delayed unit from reaching load point 5
    - Used to track missed Ready For Load (RFL)



### Problem Alert (voluntary)

- Enter an X in this field if you believe the problem with the system or component is generic to its design or operation practices
- Because this information may be helpful to others using similar equipment, an X alerts the NERC staff to initiate an investigation
- Man Hours Worked (voluntary)
  - Enter the number of man-hours spent correcting the cause of the event or making repairs
  - Include hours expended for on-site repairs as well as any off-site work



- Problem: High energy piping (HEP) failures are very rare. Less than ten have occurred since GADS started. One of your big coal units has just experienced its second HEP failure in two years. Both were due to the use of welded seam piping. Your company has repaired both failures with seamless pipe as a result.
- Question: What should you do to alert the industry to a potential problem?
  - A. Submit an event to GADS detailing the failure as much as possible
  - B. Use the appropriate cause and amplification codes
  - C. Place an X in the Problem Alert field
- Answer: C. Place an X in the Problem Alert field
- Explanation: NERC will only initiate an investigation if the Problem Alert field is marked with an X

### **Verbal Description**



- Verbal Description (voluntary but encouraged)
  - The verbal description can be the most helpful piece of information you provide if it is completed correctly
  - Comparing the verbal description to the cause code description is the only way to verify that the cause code is correct
  - While the cause code will point to the equipment with the problem or its cause, the verbal description can actually describe the event in detail
  - Your in-house system may allow you to write a book for a verbal description but only the first 86 characters get sent to NERC
    - Include the common unit name/number of the equipment and a concise description of the problem in the first 86 characters
      - Example: 1A BFPBP outboard journal bearing failure housing cracked



## **Verbal Description Comparison**

#### Method 1

- Cause Code 1000
- U1 Outage
- The unit was brought off line due to a leak

#### Method 2

- Cause Code 1000
- U1 Outage
- Water wall tube leak, level 6, front panel, tubes 21-23 eroded from stuck soot blower. Replaced tubes, soot blower lance



## **Additional Work During Event**

Section D - Additional Work During Event, col 20 - 82	04
Section D - Additional Work During Event, col 20 - 82	05

- Reporting additional work during the event is voluntary
- Same record layout as Section C, the primary cause of event
- Typically used to report
  - Factors contributing to the cause of the event
  - Additional work
  - Factors affecting startup/ramp down
- Also used to document other major equipment items worked on during outages
- Up to 48 additional work during event records allowed
  - Record Numbers would be from 04 to 99 max



## **Expanded Data Reporting**

Required

Blank

07 Event Data File: Section C - Primary Cause of Event w/Expanded Reporting for GT/JE (\*), Record 02

Data Field	Columns						
Cause Code	20-23						
Amplification Code	24-25						
Time Work Started	26-33						
Time Work Ended	34-41	 					
Blank Columns	42-43	 					
Event Contribution Code	44	 	 				
Problem Alert	45		 				
Man-hours Worked	46-49	 	 	 			
Failure Mechanism Code *	50-53		 	 			
Trip Mechanism *	54	 	 	 			
Cumulative Fired Hours *	55-60		 	 	 	•	
Cumulative Engine Starts *	61-65						
Verbal Description	66-80		 				 -
Record Number	81-82			 			

 Expanded data reporting is available for owners/operators of gas turbine/jet engines. Four additional data fields as shown above by an asterisk (\*) can be reported in Section C.



## **Expanded Data Reporting**

- Expanded data reporting is voluntary
- It is for gas turbines and jet engines only
  - Optional but strongly encouraged
- Failure mechanism code
- Trip mechanism (manual or auto)
- Cumulative fired hours at time of event
- Cumulative engine starts at time of event
- Note: the expanded reporting data fields take up extra space in Section C of the 07 event data file reducing the length of the verbal description for the primary cause of the event from 86 to 70 characters; the length of the verbal description for additional work during event records remains at 86 characters



- Problem: Your company has a lot of gas turbines and it decides to start submitting its GADS data to an outside company for more in depth analysis. The analysis involves breaking the NERC cause codes down into about 5X as many. After the initial files are sent you start getting a lot of emails and phone calls requesting more information about a lot of the events.
- Question: What is wrong with your data?
  - A. The company can't handle records for additional work during an event
  - B. You don't do expanded data reporting on your gas turbines
  - C. The verbal description is missing or very poor
- Answer: C. The verbal description is missing or very poor
- Explanation: To break the cause codes out requires a good verbal description; NERC does not require it but others do





# **Questions and Answers**

